

CHENBRO



Chassis Management Board User's Manual

80H11313101A1

July / 7 / 2009

Copyright

Copyright © 2008 CHENBRO Micom Co., Ltd.. All rights reserved.

Unless otherwise indicated, all materials in this manual are copyrighted by CHENBRO Micom Co., Ltd.. All rights reserved. No part of this manual, either text or image may be used for any purpose other than internal use within purchasing company. Therefore, reproduction, modification in any form or by any means, electronic, mechanical or otherwise, for reasons other than internal use, is strictly prohibited without prior written permission.

CHENBRO Micom Co., Ltd. reserves the right to make improvement and modification to the products indicated in this manual at any time. Specifications are therefore subject to change without prior notice.

Information provided in this manual is intended to be accurate and reliable. However, CHENBRO Micom Co., Ltd., assumes no responsibility for its use, nor for any infringements upon the rights of third parties, which may result from its use.

Trademark

All registered and unregistered trademarks and company names contained in this manual are property of their respective owners including.

Technical Support

CHENBRO works hard to offer our customers maximum performance from our chassis. But in case you have any problem with our product you can find supports from the following resources.

Web Support

Detail information of our products is in our website. You can find technical updates, installation guides, FAQs, technical specifications and more. Our web address is: www.chenbro.com.

Email Support

You can also fill out the technical support form at our [Technical Support](#) page. Your technical issue inquiries will be sent directly to our support professionals.

Phone Support

You can also contact CHENBRO HQ or branch office for immediate support; their contact information is as following:

CHENBRO HQ	CHENBRO Europe B.V.	CHENBRO Micom (USA) Inc.
Tel: 886-2-8226-5500	Tel: 31-40-295-2045	Tel: 1-909-947-3200
Fax: 886-2-8226-5423	Fax: 31-40-295-2044	Fax : 1-909-947-4300

Contents

Copyright	2
Trademark	2
Technical Support	2
Contents	3
Revision History	4
Safety Information	5
Conventions Used in this Manual	5
Introduction	5
About this Guide	5
Introducing Chenbro Chassis Management Board (CMB)	5
CMB Hardware	6
Function Switch Pin Definition (SW1)	7
System Failure & Alarm Mute Signal Pin Header (CN3)	8
CMB to M/B RS-232 or USB mode connecting selection (JP2)	8
Fan PWM Duty Cycle v.s System Temperature	8
Function Switch DIP8 Setting at On for 55°C Alarm Temperature	8
Function Switch DIP8 Setting at Off for 65°C Alarm Temperature	8
CMB Utility Installation and Operation	9
Purpose	9
System Wiring	9
Supported OS	9
Utility Installation	9
Main operation window	11
System Connection Relative Information	12
Scroll Function Menu	12
System Current Device Information	13
Status and Alarm Monitoring Pages	14
Change the Logo	17
Cabling Example	18

Revision History


Date	Modifications
July / 7 / 2009	● First Release

Safety Information

- Read the installation instructions before connecting to the power source.
- Only trained and qualified personnel should be allowed to install, replace or service this equipment.
- Never install this product in a wet environment.
- Position system cables and power cables carefully; route system cable and the power cable and plug so that they cannot be stepped on or tripped over. Be sure that nothing rests on your system component cables or power cable.

Conventions Used in this Manual

The following conventions are used in this manual.

	<p>Important Icon: Provides important information on the current topic that must not be overlooked.</p>
---	--

Introduction


About this Guide

This Chassis Management Board (CMB) user's manual provides the information for functions, capabilities, configuring and using of fan control in chassis.

Introducing Chenbro Chassis Management Board (CMB)

Chenbro CMB provides a convenient way for fan, PSU and system temperature monitoring in chassis. Via the software utility, system manager can monitor the status in operation center. The function of CMB includes fan PWM control, fan failure, system overheat, PSU failure alarm and alarm mute.

CMB Hardware



No.	Description	Function
1	SW1	DIP1~10 function setup for Fan control, temperature detection or PWM control
2	CN1, CN2	Standard 4-pin power connectors. When using up to 6x fans, it is recommended to have all power connectors connected.
3	JT1, JT2	Reference thermal sensor pin headers. Must have 2 thermal couple wires connection when fan monitoring function is enabled.
4	CN3	System failure & alarm mute signal pin headers (connecting to chassis LED board). Pin[1-2] = alarm LED; Pin[5-6] = alarm mute switch
5	CN6	PWM fan bypass pin header for M/B on-board fan control. Specified cable required for connecting to fan connectors on M/B. Meanwhile, SW1-DIP9 should be set to [OFF]
6	JA1~JA6	Group-A 8-pin fan connectors (for 8P8C double-deck fans only). SW1-DIP10 must set to [ON] when fan is connected
7	JF1~JF6	Group-B 4-pin fan connectors (for 4P4C / 3P3C fan). SW1-DIP10 must set to [OFF] when fan is connected
8	JP1	PSU failure alarm (TTL) signal connector (for redundant PSU only)
9	JM1	PSU failure alarm mute signal connector (for redundant PSU only)
10	B1	Buzzer continually alarm indicating system fan failure Buzzer dis-continually alarm indicating system temperature failure (overheat)
11	LED1	Green LED blinking indicates CMB works normal

12	CN9	RS-232 (COM port) for M/B and CMB communication. RS-232 cable is required when using CMB utility. Meanwhile the JP2 must be set to [1-2] closed.
13	CN7	Function reserved for factory programming
14	JP2	CMB to M/B RS-232 or USB mode connecting selection Pin[1-2] = RS-232 (COM Port), Pin[2-3] = USB
15	JP3	Function Reserved for I ² C function selection
16	CN4	Function Reserved for factory programming
17	CN5	External USB connector, the JP2 must be set to [2-3] closed.
18	CN8	Function Reserved for I ² C connection

	Not support mixed fan connection on Group-A and -B at same time.
--	--

Function Switch Pin Definition (SW1)


	DIP 1~6	DIP 7	DIP 8	DIP 9	DIP 10
ON	Fan1~6 Monitoring Enable independently	Temperature detecting by JT1 & JT2 Enable	Alarm Temperature is 55°C	PWM controlled by CMB	Support 8-pin connector fans (Group-A)
OFF	Fan1~6 Monitoring Disable independently	Temperature detecting by JT1 & JT2 Disable	Alarm Temperature is 65°C	PWM controlled by motherboard	Support 4-pin connector fans (Group-B)

- **DIP1~DIP6: Fan 1~6 monitoring enable [ON] / disable [OFF]**
 - When it's enabled, the thermal sensors must be connected to [JT1 & 2]
 - The fan quantity and SW1 setting enabled must be mapped
 - When all fans monitoring set to [OFF], the fans will run as non-PWM mode without any alarm function


	No matter PWM or non-PWM fan is connected, the fan monitoring function is enabled when DIP1~6 is set to "ON" position.
--	--

- **DIP7: temperature monitoring enable [ON] / disable [OFF]**
 - When it's enabled, the thermal sensors must be connected to [JT1 & 2]
 - When any fan monitoring is enabled, this DIP7 should be set to enabled at same time
 - When it's disabled, the fans will run as non-PWM mode
- **DIP8: alarm temperature setting by 55°C [ON] / 65°C [OFF]**
- **DIP9: PWM control source mode selection. Local CMB [ON] / Motherboard on-board fan connector [OFF]**
- **DIP10: Fan group selection. Group-A [ON] / Group-B [OFF]. DIP10 must be set at correct position, otherwise the fan will run as non-PWM.**

System Failure & Alarm Mute Signal Pin Header (CN3)




CMB to M/B RS-232 or USB mode connecting selection (JP2)




Fan PWM Duty Cycle v.s System Temperature

Function Switch DIP8 Setting at On for 55°C Alarm Temperature



Function Switch DIP8 Setting at Off for 65°C Alarm Temperature



Apply 2 thermal couple on JT1 & JT2 and set DIP7 to ON enabling the temperature monitoring function

CMB Utility Installation and Operation

Purpose

The CMB Utility is required when CMB is applied in Chenbro chassis.

System Wiring

Typical wiring please refers to following example (Figure-1).




Figure-1

Supported OS


Windows XP / 2000 / Server 2003 / Vista

Utility Installation

Download zipped utility file (Chenbro CMB Utility.zip) from Chenbro website.

Execute "Setup.exe" by following indication.





When setup completed, there will be a group (Chenbro CMB) and shortcut generated in the Windows start-up menu. User can verify a new device “Megawin USB” in the “COM / LPT” of device manager.




Figure-2

This utility will be operated as windows register program, a small icon will be Shown on the tooling bar when minimize the operation window.

Main operation window

There are two sub-pages for different function.

System Connection Relative Information

CMB Utility (Ver. A0)

Operation Duration: 0 day 00:01 | Mode: Local | System Time: 2009.5.22, 13:22:01

Device List (Switch Device Here)

System 1 | System 2 | System 3 | System 4 | System 5 | System 6

STATUS			ALARM		
Group A	RPM	PWM [%]			
FAN 1_1	NA	NA			
FAN 2_1	NA	NA			
FAN 3_1	NA	NA			
FAN 4_1	NA	NA			
FAN 5_1	NA	NA			
FAN 6_1	NA	NA			
Group A	RPM	PWM [%]			
FAN 1_2	NA	NA			
FAN 2_2	NA	NA			
FAN 3_2	NA	NA			
FAN 4_2	NA	NA			
FAN 5_2	NA	NA			
FAN 6_2	NA	NA			

Temperature

Temp. 1: NA

Temp. 2: NA

Threshold: 65

Switch Status

1	2	3	4	5	6	7	8	9	0
									ON
0	0	0	0	0	0	0	0	0	OFF

- 1 FAN 1 (ON:EN/OFF:DIS)
- 2 FAN 2 (ON:EN/OFF:DIS)
- 3 FAN 3 (ON:EN/OFF:DIS)
- 4 FAN 4 (ON:EN/OFF:DIS)
- 5 FAN 5 (ON:EN/OFF:DIS)
- 6 FAN 6 (ON:EN/OFF:DIS)
- 7 TEMP SENSOR (EN/DIS)
- 8 TEMP Thres. (55/65) deg.
- 9 PWM (EN/MB-ctrl)
- 0 FAN Model (A or B)

Current Device Information

System Name: System 1

M/B Model: unknown

RPS Model: unknown

COM Port: COM 1

CMB FW Version: 1.0

Link Status

Connected

CHENBRO

Status and Alarm Monitoring Pages

Figure-3

System Current Device information Area

System Connection Relative Information

This area shows the main information of connected systems, which includes:

- **Operation Duration:** This presents CMB utility program is been executed after properly connection with M/B
- **Local or Remote Mode:** The local mode is used when the CMB is connected via COM port to the M/B in the same chassis. The remote mode is used for a stand-alone server connect to an extension chassis which has CMB installed. Normally the remote mode is base on USB connection
- **System time:** This shows the target execution of the system clock.
- **Device list:** There are up to 6x system (CMB) can be monitored at one time. Factory default setting is start from system1, and normally to be the server with CMB integrated. For the system2~6, it's normally runs as "remote" mode, see Figure-4 for the connection concept.




Figure-4

Scroll Function Menu

There are several function on the menu and allow customer to use depends on real operation requirement for remote management via Ethernet (UDP).

- **Protection Mode:** This setting is operated base on preventing any improper access from remote server. However, the protection enable / disable only can be set in local mode, not the remote mode. When the protection mode is enabled, only local mode access and control is allowed. (See Figure-5)




Figure-5

- **Remote Login:** This is for host server to access the external chassis (ex. JBOD) with integrated CMB, monitor and control the CMB via Ethernet base on UDP. When execute the remote monitoring, the Ethernet networking information should be checked before a pop-up login window. Meanwhile, the password is required for accessing (See Figure-6).




Figure-6

- **Change Password:** This is for the protection mode password change, only base on “local mode” administration.



System Current Device Information


This area provides the user-define information input which includes System Name, M/B model, RPS model, and connection COM port. User can save the data as a file.




Status and Alarm Monitoring Pages

This area includes the major information of environment status and alarm information.

- **Status:** This page include the monitoring of “Fan status”, “Temperature status”, SW1 “Switch setting”, and CMB “Link status”.
 - **Fan monitoring:** when PWM fan(s) connected, the RPM and PWM (%) mode will be detected and shown on the relative column. (See Figure-7 a.)

 Fan Group-A or -B will be automatically detected, and the default setting is Group-A. (See Figure-7 b.)

 According to Group-A application, the bottom group is only activated when 8P8C “double-deck fan” is connected. When the SW1-DIP1~6 is set to “OFF”, all the columns of fan status will show “NA”. (See Figure-8)




Figure-7





Figure-8

www.chenbro.com

- Temperature monitoring: this area shows the real environment temperature when the thermal sensors are connected and SW1-DIP7 is set to “ON” position. (Showing “NA” when DIP7 set to “OFF”, see Figure-9 a.). The threshold shows the definition of alarm temperature. It’s automatically detected according to DIP8.

 When the thermal sensor is not connected, the fan monitoring function will be disabled automatically or PWM fan runs up to 100% mode. (See Figure-9 b.)




Figure-9

- SW1 status: this shows the setting position of SW1 DIP1~10 on CMB. (See Figure-9 c.) Figure-9 d. shows the function description of SW1.
- Link Status: When a CMB is connected to M/B via COM port with this CMB utility operation, a message will show “Connected”, and message “Polling” shows every 3 seconds to check the linking status. (See Figure-9 e.) If there is no cable connection, this status will show “Disconnected”, and all the monitoring function is disabled. (See Figure-10)




Figure-10

- **Alarm Notification:** This page shows all the monitored devices status. When any alarm is triggered, the relative column will change to corresponding messages and defined colors. If user mute the buzzer via alarm mute switch at front control panel (connected to CN3), the failure LED will remain enabled until alarm event is fixed.

Figure-11 shows the failure status with alarm mute triggered.

The redundant PSU failure only be enabled when PSU module failed or un-installed. It's not support the voltage monitoring.



Figure-11

- **Alarm (Pop-up) Window:** When any alarm event is triggered, a pop-up window (see Figure-12) is shown to notify administrator.



Figure-12

- Alarm Log File: Open the event log file (see Figure-13) to read detail alarm information (see Figure-14).




Figure-13





Figure-14

Change the Logo

User may change the default “CHENBRO” logo with the following process.

- Create user own logo file: The picture format must be BMP file.
The pixel must be 227 x 40.
The file name must be productlogo.bmp
- Copy the new file to C:\Program Files\CMB\others to instead the original one.



Cabling Example

