


Storage Solution

# R&S<sup>®</sup> SpycerBox

## Ultra TL

Hardware Guide







Hardware Guide Version 1.0 for the SpycerBox TL hardware version 1.0

Copyright © 2015 by Rohde & Schwarz DVS GmbH, Hanover. All rights reserved.

The manuals as well as the soft- and/or hardware described here and all their constituent parts are protected by copyright. Without the express permission of Rohde & Schwarz DVS GmbH any form of use which goes beyond the narrow bounds prescribed by copyright legislation is prohibited and liable to prosecution.

This particularly applies to duplication, copying, translation, processing, evaluation, publishing, and storing and/or processing in an electronic system.

Specifications and data may change without notice. We offer no guarantee that this documentation is correct and/or complete. In no event shall Rohde & Schwarz DVS GmbH be liable for any damages whatsoever (including without limitation any special, indirect or consequential damages, and damages resulting from loss of use, data or profits, or business interruption) arising out of the use of or inability to use the hardware, software and/or manual materials.

Those parts of this documentation that describe optional software or hardware features usually contain a corresponding note. Anyway, a lack of this note does not mean any commitment from Rohde & Schwarz DVS GmbH.

DVS and Spycer are registered trademarks of Rohde & Schwarz DVS GmbH. Linux is a registered trademark of Linus Torvalds.

Any other product names mentioned in this documentation may be trademarks or registered trademarks of their respective owners and as such are subject to the usual statutory provisions.



---

**Headquarters:**

Rohde & Schwarz DVS GmbH  
Krepenstr. 8  
30165 Hannover  
GERMANY

Phone: +49-511-67807-0  
Fax: +49-511-630070  
E-mail: [info.dvs@rohde-schwarz.com](mailto:info.dvs@rohde-schwarz.com)  
Internet: <http://www.dvs.de>

**Support:**

Phone: +49-511-67807-125  
Fax: +49-511-371985  
E-mail: [service.dvs@rohde-schwarz.com](mailto:service.dvs@rohde-schwarz.com)



# Contents

<b>1</b>	<b>Introduction</b> .....	1-1
1.1	Target Group .....	1-1
1.2	Conventions Used in this User Guide .....	1-1
1.3	Safety Instructions .....	1-4
1.4	Important Notes .....	1-6
<b>2</b>	<b>Overview</b> .....	2-1
2.1	Variants of the SpycerBox Ultra TL .....	2-1
2.2	Overview of the Front .....	2-1
2.3	Overview of the Interior .....	2-4
2.3.1	Hard Disk Array .....	2-4
2.4	Overview of the Rear .....	2-5
2.4.1	System Disk Array .....	2-6
2.4.2	ATX Connector Panel .....	2-7
2.4.3	Power Supply .....	2-8
2.4.4	Slot Panel Connectors .....	2-9
2.5	Cache Protection Unit .....	2-12
<b>3</b>	<b>Installation</b> .....	3-1
3.1	Preparations .....	3-1
3.2	Opening the Casing .....	3-2
3.3	Installing the Hard Disks .....	3-3
3.4	Closing the Casing .....	3-5
3.5	System Setup .....	3-5
3.6	Note about the Network Installation .....	3-6
<b>4</b>	<b>Operation</b> .....	4-1
4.1	Lifting the Faceplate .....	4-2
4.2	Starting the System .....	4-3
4.3	R&S DVS SAN Remo .....	4-4
4.4	Shutting Down the System .....	4-5



<b>5</b>	<b>Maintenance</b> .....	5-1
5.1	Disk Maintenance .....	5-2
5.1.1	Introduction to RAID .....	5-2
5.1.2	Identifying a Broken Disk .....	5-3
5.1.3	Replacing a System Disk .....	5-5
5.1.4	Replacing a Hard Disk of the Storage Array .....	5-7
5.2	Controller Maintenance .....	5-11
5.3	Power Supply Maintenance .....	5-14
5.4	Backup or Recovery of the System Disk .....	5-16
5.4.1	Creating a Backup Image of the System Disk .....	5-16
5.4.2	Restoring the System Disk .....	5-18
<b>A</b>	<b>Appendix</b> .....	A-1
A.1	Troubleshooting .....	A-2
A.2	Technical Data .....	A-4
A.2.1	General Technical Data .....	A-4
A.2.2	Dimensions .....	A-5
A.3	Packing Instructions .....	A-6
A.4	Conformity Declarations .....	A-9
A.4.1	RoHS Compliance .....	A-9
A.4.2	EC Declaration of Conformity (CE Marking) .....	A-9
A.4.3	FCC Compliance Statement .....	A-10
<b>I</b>	<b>Index</b> .....	I-1

# Introduction

## 1.1 Target Group

To use this manual you should know how to handle computer equipment. Furthermore, to connect the R&S DVS system to a network or a SAN storage you should have experience as a network administrator and know how to set up the required network connections on the installation site in hard- as well as software.

When performing maintenance tasks on the hardware of the R&S DVS system, you must be qualified to work on, repair and test electrical equipment.

## 1.2 Conventions Used in this User Guide

The following typographical conventions will be used in this documentation:

1. Texts preceded by this symbol describe activities that you must perform in the order indicated.
  - Texts preceded by this symbol are parts of a list.
    - Texts preceded by this symbol are parts of a list of a second level.
  - Texts preceded by this symbol are parts of a requirements list.
    - ▶ Texts preceded by this symbol describe the result of an action.



Texts preceded by this symbol are general notes intended to facilitate work and help avoid errors.

### **NOTICE**

#### **Cause of Risk**

Indicates the possibility of incorrect operation which can result in damage to the product. You must pay particular attention to text that follows this symbol to avoid errors.

**Preventive measures to avoid risks of damage to the system.**



	<p><b>Source of Danger</b></p> <p>Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.</p> <p><b>Preventive measures to avoid minor or moderate injury.</b></p>
	<p><b>Source of Danger</b></p> <p>Indicates a hazardous situation which, if not avoided, can result in death or serious injury.</p> <p><b>Preventive measures to avoid death or serious injury.</b></p>
	<p><b>Source of Danger</b></p> <p>Indicates a hazardous situation which, if not avoided, will result in death or serious injury.</p> <p><b>Preventive measures to avoid death or serious injury.</b></p>

- “ ” Texts enclosed by quotation marks are references to other manuals, guides, chapters, or sections.
- ‘ ’ Texts enclosed by single quotation marks are references to labelings given by the author and quoted labelings.

<b>'Window'</b>	Text in bold with single quotation marks indicates a window name
<b>BUTTON</b>	Text in small caps and bold indicates a push button
<b><i>Group/Menu</i></b>	Text in italic and bold indicates either a group name, menu name or options in a menu list
<b><i>Menu &gt; Option</i></b>	In the specified group or menu select the stated item.
<b>Item</b>	Text in bold only stands for other labeled items of a user interface
<i>Directory/File</i>	Directory structure or file
Entry	Indicates parameters or variables, as well as selections or entries made in a program; it may also indicate a command (e.g. at a command line), a syntax or contents of a file/output
[Key]	An individual key or a key combination on a keyboard



## Keyboard Shortcuts

To perform options or procedures with the keyboard often requires a simultaneous pressing of two keys.

Example:

[Ctrl + F1]	If this is given, hold down the [Ctrl] key and press simultaneously the [F1] key.
[Alt, F1]	If this is given, press the [Alt] key first and then the key [F1] successively.

## Screenshots

The screenshots shown in this documentation may be taken on various operating systems as well as from pre-release versions of the software. Their appearance may differ from your environment. However, they should contain all relevant elements that you need to understand the described actions.



## 1.3 Safety Instructions

To use the SpycerBox Ultra TL correctly please heed the following:

### NOTICE

#### Noncompliance with safety instructions

If the R&S DVS system is not used in compliance with the safety instructions, the warranty and all resulting liability claims will be void.

**Please read the following safety instructions carefully before attempting any installation and/or performing any work on the SpycerBox hardware.**

### General

The SpycerBox Ultra TL has been built according to the applying safety regulations. To minimize the possibility of a faulty operation of the device all manuals and guides must be available at all times at the operation site. Before installing and/or using the R&S DVS system the manuals and guides delivered with it must be read and observed.

- Use the R&S DVS system only in apparent good technical order.
- The hardware of the R&S DVS system works with voltages that can be hazardous to your health. Never work on the system or access its interior with the power cable(s) being plugged in. Make sure the power supply is disconnected from the components you intend to work on.
- Computer hardware contains components that are sensitive to electrostatic discharge. If you touch them without precautionary measures, they can be destroyed. Use a wrist strap connected to ground when accessing electronic parts and take care of grounding the system. Avoid touching the internal components of the R&S DVS system whenever possible.
- Computer hardware contains components that are sensitive to changing voltages. Connecting or disconnecting the R&S DVS system to or from peripheral hardware while any of them is switched on may damage the hardware. Switch off all peripheral hardware before connecting or disconnecting anything.
- Use, store and transport the R&S DVS system only in compliance with the technical data laid out in section "Technical Data" on page A-4.
- If fluids or solid objects get inside the casing, the R&S DVS system must be disconnected from the power supply immediately. Before using the R&S DVS system again, it has to be checked by authorized service personnel.
- Only use a damp tissue without any cleaning agents to clean the casing.



- The R&S DVS system must not be misused, abused, physically damaged, neglected, exposed to fire, water or excessive changes in the climate or temperature, or operated outside maximum rating.
- Do not perform any changes or extensions to the R&S DVS system whatsoever.

### **Transportation**

The SpycerBox Ultra TL is a very sensitive device. Especially the hard disks of the system must be handled with great care. Therefore, observe in case of transportation:

- Handle the R&S DVS system with great care.
- Always use the original packing or a similar structured packing for transportation as detailed in section "Packing Instructions" on page A-6.
- Avoid shocks or vibrations during transport. For longer distances it is recommended to use a lifting truck.
- Keep the R&S DVS system as a transportation good dry.
- In the warranty period you have to keep the original packing and use it in case of transportation.

### **Environmental Conditions**

For error-free working and a long service life the SpycerBox Ultra TL needs some basic environmental conditions:

- Do not expose the R&S DVS system to sources of heat, such as direct sunlight or a radiator.
- Do not cover or obstruct the ventilation holes of the system.
- When installing the R&S DVS system in a rack, take care that warmed up air is conducted to the rear of the rack and properly vented away.
- Avoid areas with high humidity or dust. Best operating conditions are given in an air-conditioned site.
- Do not expose the R&S DVS system to strong electric or magnetic fields.
- Avoid areas where the R&S DVS system will be subject to vibrations or shocks.



## 1.4 Important Notes

The following provides information about warranty, a note about the conformity of the product and some other general information.

### Warranty Information

This product is warranted to be free of defects in materials and workmanship for a period of one year from the date of purchase. R&S DVS extends this Limited Warranty to the original purchaser.

#### NOTICE

#### Incorrect packaging

This warranty will be void if you do not transport the R&S DVS device in the original packing.

**You have to keep the original packing and use it in case of transportation. The drives must always be packed separately.**

In the event of a defect or failure to confirm to this Limited Warranty, R&S DVS will repair or replace the product without charge. In order to make a claim under this Limited Warranty, the purchaser must notify R&S DVS or their representative in writing of the product failure. In this Limited Warranty the customer must upon R&S DVS's request return the product to the place of purchase or send the defective device to a given address for the necessary repairs to be performed. In the warranty period the customer must keep the original packing and pack the R&S DVS product in it in case of a product return. If the customer is not satisfied with the repair, R&S DVS will have the option to either attempt a further repair, exchange the product or refund the purchase price.

This warranty does not cover:

- Products not developed by Rohde & Schwarz DVS GmbH.
- Products not used in compliance with the safety instructions detailed in section "Safety Instructions" on page 1-4.
- Products on which warranty stickers or product serial numbers have been removed, altered or rendered illegible.
- The costs of installations, removals, transportations, or re-installations.
- Costs for transportation damages.
- Damages caused to any other item.
- Any special, indirect or consequential damages, and damages resulting from loss of use, data or profits, or business interruption.

## Declaration of Conformity



This product has been tested according to the applying national and international directives and regulations. Further information about this can be found in section “Conformity Declarations” on page A-9.

## Product Disposal (B2B)

Used electrical and electronic products should not be disposed of with general household waste. At the end of its service life you may return the R&S DVS product after appropriate prior notification to either your local distributor or R&S DVS in Germany. R&S DVS will then take the device free of charge to a waste disposal organization which will recycle and reuse it environmental friendly.



## General Notes

Please observe the following general important notes:

### NOTICE

#### Storage capacity exceeded

In case of a full storage performance losses may occur.

**Leave about 20% of the overall main storage capacity empty of data for performance reasons.**

### NOTICE

#### Operating system updates and security patches

R&S DVS provides only tested and certified updates and security patches which will be delivered after the official release of the update or, in case of incompatibility, will not be delivered at all.

Installing uncertified operating system updates and security patches may have a negative impact on the system’s performance.

**Performing OS updates and installing security patches, which are not certified by the R&S DVS is done at your own risk. It is the customer’s responsibility to provide for a secured network.**



**NOTICE**

**Installation of third-party software**

Your R&S DVS system has been tested thoroughly and is very reliable. However, because of the vast amount of third-party software available, its reactions on the installation of such could not be tested. The installation of third-party software may disrupt the real-time capability and/or limit the functionality of your system.

**When installing third-party software, make sure that it does not interrupt and/or limit any functionality of the system.**

# Overview

## 2.1 Variants of the SpycerBox Ultra TL

The SpycerBox Ultra TL provides high-performance nearline storage for mid-term archive including the support of all uncompressed and compressed formats up to 4K. Furthermore, you can monitor the whole infrastructure or perform an easy maintenance due to a modular back-plane tray design. The SpycerBox Ultra TL can be delivered in two different hardware variants depending on, for example, the amount of the storage or the performance that is required. The following variants are available:

- Half: SpycerBox Ultra TL using 24x3.5" SATA (enterprise) hard disks and providing a storage capacity of up to 144 TB
- Full: SpycerBox Ultra TL using 48x3.5" SATA (enterprise) hard disks for up to 288 TB of storage capacity
- JBOD: SpycerBox Ultra TL using 48x3.5" SATA (enterprise) hard disks for up to 384 TB of storage capacity

## 2.2 Overview of the Front

This section provides an overview of the front of the system:




Figure 2-1: Overview of the front with a front cover



The front of the system is equipped with a removable front cover to protect the three main cooling fans on the front plate and provide sufficient air circulation.



Figure 2-2: Overview of the front without a front cover

With the operation items at the system's front the hardware of the SpycerBox Ultra TL can be controlled (e.g. turned on or off). There you can also find LEDs that allow you to assess the state of the R&S DVS system as well as USB connectors.




Figure 2-3: Operation items overview

No.	Item	Explanation
1	mute	<p>In case of a hardware malfunction a system alarm turns on. By pressing this button the alarm buzzer can be switched mute. Use a thin, pointed object to press this button.</p> <p> Some alarms (e.g. the one in case of a disk failure) are independent of the system alarm and cannot be switched mute with the mute button.</p>
2	reset	<p>Resets your system and initiates a reboot. Use a thin, pointed object to press this button.</p> <p><b>NOTICE</b> <b>Data loss</b> When resetting the system without having saved data, data may get lost. <b>Save your data before resetting the system.</b></p>
3	power	The power switch turns the system on or off.
4	LAN 1	Indicates the presence of network connection on port LAN 1.
5	LAN 2	Indicates the presence of network connection on port LAN 2.
6	alarm	Indicates alarm in case of hardware malfunction, please contact R&S DVS service team.
7	power status	Indicates that the system is powered on.
8	-	Disabled
9	USB ports	USB 2.0 input

 Lift the faceplate to have a better overview on the LEDs and estimate the current state of the system, see section “Lifting the Faceplate” on page 4-2.

Further information about what to do in case of an alarm can be found in section “Troubleshooting” on page A-2.



## 2.3 Overview of the Interior

This section provides an overview of the system's interior.

### 2.3.1 Hard Disk Array

The hard disks of the storage hard disk array are used, for example, to store proxy clips of your video and audio material or backup files of the connected central storage. It is the main storage of the R&S DVS system. To prevent data loss in case a hard disk fails, it is normally RAID protected.



Further information about RAID can be found in section "Introduction to RAID" on page 5-2.

The system disks (SSD) are not among the hard disks of the hard disk array. They can be found in the system disk array (see section "System Disk Array" on page 2-6).

Once the top cover is lifted, you have access to the hard disk array:




Figure 2-4: SpycerBox Ultra TL disk array



At shipment, the hard disks are delivered separately and therefore have to be installed before putting the system into operation, see section "Installing the Hard Disks" on page 3-3

## 2.4 Overview of the Rear

This section provides an overview of the rear of the system:




Figure 2-5: Overview of the rear

<p>system disk array</p>	<p>The system disk array contains the SSDs for the operating system and metadata. You can find further information about this in section "System Disk Array" on page 2-6.</p>
<p>ATX connector panel</p>	<p>On this panel you can find the standard connectors of the computer system. Further information about them can be found in section "ATX Connector Panel" on page 2-7.</p>



power supply	The redundant power supply provides the system with power. It consists of several independent power supply units: Even if one fails the others will still supply enough power to keep the system operational. Further information about the power supply can be found in section “Power Supply” on page 2-8.
slot panel connectors	The slot panel connectors of the R&S DVS system provide, for example, the network connections to connect the system to a SAN. Furthermore, if applicable, some additional panels may be present for internal reasons or on customer request. More details about the slot panel connectors can be found in section “Slot Panel Connectors” on page 2-9.

### 2.4.1 System Disk Array

The system disk array at the rear of the system contains SSDs for the operating system and metadata. To prevent data loss in case a disk fails, they are normally RAID protected. Furthermore, these disks are protected with a cache protection unit to prevent data loss, for instance, in case of a power failure.



More information about RAID can be found in section “Introduction to RAID” on page 5-2. The backup unit is described in section “Cache Protection Unit” on page 2-12.




Figure 2-6: System disk array

The system SSDs are connected to the system with the help of disk carriers which make the removal of a disk easy, for example, in the event of a failure.

 The hard disk array of the storage and the system SSDs are mounted using different carriers. Thus, they are installed differently into the system. Further information about how to remove and exchange a SSD can be found in section “Disk Maintenance” on page 5-2.

**NOTICE** **Disk fail in the same RAID array**  
Storage disk array: If a third disk within the same disk set fails in the meantime, the data will be unrecoverable.  
System disk array: If the second disk fails in the meantime, the data will be unrecoverable.  
**Replace a broken disk immediately.**

## 2.4.2 ATX Connector Panel

The ATX connector panel on the rear of the R&S DVS system holds the connectors of the computer system. It provides the following connections:




Figure 2-7: ATX connector panel on the rear of the SpycerBox Ultra TL

No.	Item	Explanation
1	COM port	RS-232 connector for the connection of serial interface devices



No.	Item	Explanation
2	IPMI	Dedicated LAN port for IPMI 2.0 (Intelligent Platform Management Interface) providing KVM (Keyboard, Video, Mouse redirection) as well; for further information see the documentation(s) of the original manufacturer(s)
3	LAN (10 Gb)	10 Gb Ethernet Copper (10000BASE-T) connection ports to connect the system to a network
4	VGA	DB-15 connector (female) to connect a monitor; normally with an extra graphics card installed, this connector will not be operational; however, it can be used in combination with IPMI/KVM for system management; if you want to use this port, please contact R&S DVS directly in case of setup questions
5, 6	USB ports	These USB connectors (universal serial bus) offer you the possibility to connect other devices to your system

### 2.4.3 Power Supply

The redundant power supply provides the system with power. It consists of several independent power supply units: Even if one fails the others will still offer enough power to keep the system working.

#### **NOTICE**

#### **Second power supply failure**

The system can be operated with one power supply unit out of order. However, if another one fails, a continued operation of the system cannot be guaranteed.

**It is recommended to change a failed power supply unit immediately (see section "Power Supply Maintenance" on page 5-14).**

The following provides an overview of one of the power supply units:




Figure 2-8: Overview of power supply unit

handle	With the handle of the power supply unit you can pull the unit out of the power supply once it is unlocked with the latch.	
LED	The LED indicates the state of the power supply unit:	
	green	Operating normally
	off	Standby mode
latch	off (alarm LED on)	
	Disconnected from power or malfunction	
power cable socket	The socket where the power cable has to be plugged in to provide the system with power.	

## 2.4.4 Slot Panel Connectors

The SpycerBox Ultra TL provides on its slot panel connector area several connection possibilities such as the network ports or ports to connect the system to a SAN. The following figure shows an example configuration of the slot panel connector area:




Figure 2-9: Example of a slot panel configuration on the SpycerBox Ultra TL

The above layout of the slot panel area is just an example. The one at your system may differ from the figure above: The position of the individual slot panels may vary and/or other panels may be installed, either for internal reasons or on your request. The slot panels showing **Expansion** or **Option** in the figures above represent empty slot panels for optional cards that you can order.

No.	Item	Explanation
1	RAID controller	Manages the hard disks of the storage array.
2	Expansion slot	Expansion slot for a second RAID controller
3	Expansion slot	Expansion slot for NAS connectivity
4	Graphics card	Provides a DVI-I and a DisplayPort to connect a monitor to.
5	High Availability Option	Provides a dual-port 10 Gigabit Ethernet connection interface for data mirroring.



No.	Item	Explanation
6	SAN connectivity	Provides a dual-port or quad 16 Gigabit Fibre Channel connection interface.
7	4 x USB port	USB 3.0 connection interface



## 2.5 Cache Protection Unit

To prevent data loss especially for the metadata, the system provides a zero-maintenance flash-based unit for cache protection. It features a flash memory and capacitor technology that save cached data if a system power loss occurs. The capacitor charges automatically while the system is booting to provide instant cache protection upon startup, and is fully charged in a few minutes.

The cache protection unit is located inside the casing under the system disk array.



If the system's operation gets interrupted, for example, in case of a power failure, it will provide power to the cache of the connected RAID controller, so that buffered data will not get lost. Once the operation of the system is restored, the cached data will be written to the disks.

# Installation

## 3.1 Preparations

This section describes the setup of the SpycerBox Ultra TL hardware. The system must be installed properly before you can start working with it.

To install the hardware of the SpycerBox Ultra TL perform the following:

1. Unpack the R&S DVS system and its accessories.



Check your delivery and compare it with the delivery note included in the package on an extra sheet of paper. In case of missing items, please contact your local vendor or R&S DVS immediately.

### NOTICE

#### **Incorrect packaging/original packing not available**

The warranty will be void if you do not transport the R&S DVS device in the original packing.

**You have to keep the original packing and use it in case of transportation.**

2. Place the R&S DVS system on a firm, flat surface within reach of a power outlet or mount it in a rack. For good air circulation and cooling make sure the ventilation holes are not covered.

The system is now prepared for installation.

## 3.2 Opening the Casing

To open the casing of the R&S DVS system perform the following:

### DANGER

#### High voltages

The system you are working on operates with voltages that can be hazardous to your health.

**Never work on the system or access its interior with the power cable(s) being plugged in. Make sure the power supply is disconnected from the components you intend to work with.**



The system must be operated only with the chassis' cover installed to ensure proper cooling.

1. Disconnect all power cords from the system.
2. Unscrew the eight screws to detach the two covers. Slide both covers backwards and remove them.




Figure 3-1: Removal of the cover of the casing

### 3.3 Installing the Hard Disks

The hard disks are delivered in a separate packing and have to be installed prior to using the system.

 Each hard disk is labeled with its exact position within the array. There are two hard disk sets, one each for the left and the right side.

The disk assignment is as follows:





Figure 3-2: Assignment of the hard disks


Perform the following steps:

1. Unlatch the disk carrier of the hard disk by pulling up the opener of the disk carrier.






2. Carefully place the carrier from above and close the handle to mount the HDD. Observe the correct hard disk assignment.



## 3.4 Closing the Casing

After finishing your task at hand you have to close the casing of the R&S DVS system again. For this perform the following:

1. Put the covers back on and slide them into place until they lock.
2. Fasten the eight screws.



With this the task of closing the casing is finished and you can turn the system back on at any time.

## 3.5 System Setup

This section describes the setup of the SpycerBox Ultra TL hardware. The system must be installed properly before you can start working with it.

1. Connect at least the following computer peripherals:
  - Mouse,
  - keyboard and
  - a monitor that is operable at a resolution of at least 1280 × 1024 pixels (default manufacturing setting).
2. Connect any other peripheral computer equipment. For an overview of the panels and connectors at the system's rear see section "Overview of the Rear" on page 2-5.
3. Connect the power cable(s) to the system.



The SpycerBox Ultra TL hardware is now properly installed and you can switch on the system as described in section “Starting the System” on page 4-3.

## 3.6 Note about the Network Installation

Because of the amount of possible workflows that customer’s may use the SpycerBox Ultra TL for as well as network connections (see section “Slot Panel Connectors” on page 2-9), this document does not describe how to connect the R&S DVS system to a network or central storage. On the R&S DVS web page ([www.dvs.de](http://www.dvs.de)) you can find some diagrams showing how the SpycerBox Ultra TL may fit in a workflow/network.

To connect the R&S DVS system to a network/central storage you should have experience as a network administrator and know how to set up the required network connections on the installation site in hardware as well as software. In case you experience difficulties during the installation, R&S DVS offers you special assistance that will be tailored to your personal needs and which can range from remote diagnosis to on-site services. Please contact the R&S DVS service department for further information.

# Operation

This chapter describes how to operate the SpycerBox Ultra TL hardware, i.e. it is explained how to start the system and how to shut it down. For both procedures you have to use the power switch of the operation items at the front of the system.




Figure 4-1: The power switch

Additionally, the configuration management software SAN Remo is described briefly which allows you to configure, reboot and shut down the SpycerBox Ultra TL.



All other items necessary for a correct operation of the SpycerBox Ultra TL hardware, such as the LEDs or the buttons, are described in chapter "Overview" on page 2-1.




## 4.1 Lifting the Faceplate

The faceplate of the system can be lifted to access the operation items or completely removed e.g. for transports. For this perform the following:

1. When in front of the system lift the lower edge of the plate up towards you. Now the operation items panel is accessible.



2. If desired, remove the faceplate by leveling it horizontally and pulling it towards you.



To reassemble the faceplate reverse the above steps.

## 4.2 Starting the System

After a proper installation of the system (see chapter “Installation” on page 3-1) you may start the R&S DVS system at any time.

To start the system perform the following:

- Press the power switch briefly to turn on the system.

As with any standard computer after initial booting, the system begins to load the installed operating system.



During the start-up of the system several alarm beeps will be sounded. This is part of a self-test and does not indicate an error or malfunction.

When the operating system has finished its loading, you can begin to work with the R&S DVS system right away.



## 4.3 R&S DVS SAN Remo

R&S DVS's configuration management software SAN Remo can be used to configure, reboot and shut down the SpycerBox Ultra TL.

SAN Remo will run in the web browser (Mozilla Firefox version 4 and higher, Internet Explorer version 11 and higher, Google Chrome and Safari) on every client in the network. The address is either the localhost (127.0.0.1) or the IP address of the SpycerBox Ultra TL in the network. After starting it, you have to enter a user name (default: admin) and password (default: admin).




Figure 4-2: Plugin view in the SAN Remo software

With SAN Remo you can change the configurations of the R&S DVS system (e.g. its IP address or Fibre Channel connections). Select the system represented by a node and click on the respective icon to view and change the settings. Afterwards you will see all options that can be changed. With the monitoring feature you can obtain a graphical overview of certain properties of different nodes.

SAN Remo can also be used to gather log files of the system, for example, for troubleshooting. By default they will be saved in a single archive file on the desktop of your system.

Additionally, you can reboot or shut down the R&S DVS system with SAN Remo.

## 4.4 Shutting Down the System



For a complete description of the features of SAN Remo and how to use it refer to the “SAN Remo Configuration Management” supplement.

How to use SAN Remo for the SpycerBox High Availability Option is described in the “SpycerBox High Availability Administration Supplement”.

There are several possibilities to shut down the R&S DVS system. All depend on whether the operating system is already loaded, frozen or not completely loaded. Please act accordingly.

To shut down the system perform the following according to the state of the system’s operating system:



After a shut-down wait at least ten seconds before starting the system again. This time is needed to safely erase all memory banks of the system.

### **With the operating system fully loaded**

If the operating system is up and running, there are two ways to shut down your system:

- Turn the system off by shutting down the operating system the usual way (see also section “R&S DVS SAN Remo” on page 4-4).

The operating system will then save your personal settings and once it has ended, the system will turn off.



Alternatively, you can initiate a fast shut down by pressing the power switch briefly.

Some settings will be saved and afterwards the system turns off.

### **With the operating system frozen or not completely loaded**

If the operating system is not responding anymore or not completely loaded, perform the following:



This procedure can cause corrupted system data. However, the system should be sufficiently protected against this by the journaling file system and the battery backup unit (see chapter “Cache Protection Unit” on page 2-12).



- Shut down the system by pressing the power switch until the system turns off.

The system will then shut down immediately.



# Maintenance

This chapter explains the maintenance work that you can perform on your own. For each work a detailed procedure description is given. If you experience trouble with the system that cannot be resolved with the work described here or in section “Troubleshooting” on page A-2, please contact your local vendor or R&S DVS directly.



## 5.1 Disk Maintenance

This section deals with the possible event of a disk failure. First, some introductory information about RAID are provided. After that follow descriptions how to act when a disk fails.

### 5.1.1 Introduction to RAID

In a system where huge amounts of data are processed, large storage capacities combined with high data throughputs are mandatory. To provide both at the same time it is common practice in the area of video and digital film to configure several disks together into a stripe set or RAID. The IT world has defined several 'levels' of RAID, most of them providing some kind of data protection.

The RAID feature makes the R&S DVS system tolerant of disk failures. Even with a broken disk operations can still be continued and, once the failed disk has been replaced, the missing data can be recovered easily. The data protection is provided by RAID controllers installed inside the system. Each controller independently administers the data protection for the set of disks that is connected to it.

The system/metadata disk array comprises two SSDs. They are connected to a RAID controller that applies a RAID 1 to the data, meaning that they are protected by a mirroring of the data between two disks. If one of the SSDs fails, the missing data can be restored with the mirrored information stored on the other disk.

The main storage of the R&S DVS system comprises up to 48 hard disks in the SpycerBox Ultra TL. These are connected to a RAID controller which applies a RAID 6 to the data. With this, the data is striped across these hard disks during write procedures. At the same time the information necessary to rebuild a failed hard disk (parity information) is generated and written across the disks as well. With the parity information written, two hard disks per disk set (RAID pack) can fail and your data will still be recoverable due to the information stored on the other disks. Optionally, a second controller can be installed to boost performance or to connect a JBOD.

#### **NOTICE**

#### **Disk fail in the same RAID array**

Storage disk array: If a third disk within the same disk set fails in the meantime, the data will be unrecoverable.

System disk array: If the second disk fails in the meantime, the data will be unrecoverable.

**Replace a broken disk immediately.**

The left and right hard disk sets represent a RAID pack each:




Figure 5-1: Disk sets (RAID packs)

With the available RAID feature the R&S DVS system can withstand disk failures without losing data or access to data.

### 5.1.2 Identifying a Broken Disk

In case of an alarm or when suspecting a defective disk, you have to identify the broken disk first in order to replace it.

i

An alarm can be caused by a number of reasons. Please refer to section “Troubleshooting” on page A-2 first for further details about what to do in case of an alarm.

If a disk fails, the alarm will be sounded by a RAID controller. It cannot be switched mute with the mute button of the operation items. It can be turned off either with the RAID software manager or by replacing the broken disk.

Data accesses to the disk array are still possible because any missing data will be recalculated from the parity information stored on the other disk(s). This can limit the overall performance and real-time operations may no longer be possible.

**NOTICE****Disk fail in the same RAID array**

Storage disk array: If a third hard disk within the same disk set fails in the meantime, the data will be unrecoverable.

System disk array: If the second SSD fails in the meantime, the data will be unrecoverable.

**Replace a broken disk immediately.**



The hard disk array of the storage and the system SSDs are mounted using different carriers. Thus, they are installed differently into the system.

In most cases you can find the broken disk by simply observing the LEDs of the disk array (see section “Hard Disk Array” on page 2-4 and section “System Disk Array” on page 2-6).

**System Disk Array**

- no longer blinking (either continuously on or off),
- irregularly blinking compared to the other SSD of the same disk set, or
- showing a disk or disk carrier related error (see section “System Disk Array” on page 2-6).

**Storage Disks Array**

A red LED on the disk carrier will indicate malfunction.




Figure 5-2: Alarm LED

Once the broken disk has been identified, you can replace it as described in section “Replacing a System Disk” on page 5-5 and section “Replacing a Hard Disk of the Storage Array” on page 5-7.

**NOTICE****Wrong disk replaced**

Replacing the wrong disk, i.e. a good one instead of the broken one, may result in a total loss of data.

**If you are unsure about having detected the correct disk please contact the R&S DVS service department.**

### 5.1.3 Replacing a System Disk

As soon as the broken disk of the system has been identified (see section "Identifying a Broken Disk" on page 5-3), it can be replaced easily.



Before replacing a SSD you have to gather the log files of the RAID controller. If you know how to do this you may proceed on your own. If not, please contact the R&S DVS service department first.

#### Removing the System Disk

The SSDs are connected to the system with the help of disk carriers. They can be removed easily, even when the system is running (hot-swappable).



For an overview of the disk carrier as well as further information about it see section "System Disk Array" on page 2-6.

To remove a system disk perform the following:

1. If appropriate, stop all accesses to the SSDs of your system, for example, by exiting the software and severing the network connections.
2. Unlatch the disk carrier of the defective disk by pulling out the opener of the disk carrier (1).

*SpycerBox Ultra TL and system disk:*




Figure 5-3: Pulling out the lever

This takes the SSD installed in the disk carrier out of the system's interfaces inside.



3. Once the interface connections inside the system are severed, you can pull the disk carrier out of the system.

Now the SSD is removed from the system and it has to be replaced in the next step.

### Replacing the System Disk

To replace a system disk do the following:

#### NOTICE

#### Incorrect handling of the SSDs

Significant environmental changes, for example, altitude, voltage, temperature, shock, vibration, etc., can damage a disk.

**Handle SSDs with great care.**

1. Unscrew the screws that fix the disk to the disk carrier.
2. Exchange the broken disk with a new one and assemble it in the disk carrier with the screws.



It is best to use the same brand and type of disk again. Otherwise a loss of performance might occur.

After that the SSD is replaced and the disk carrier with the new disk has to be reassembled in the system.

### Reassembling the System Disk

After replacing the disk, the disk carrier with the new SSD has to be reassembled in the system. For this perform the following:

1. Slide the disk carrier back into its shaft at the disk array.
2. Push the disk carrier completely back into the shaft by applying pressure to the disk carrier directly (i.e. do not use the lever to push the carrier). Move it until you feel the resistance of the disk interface inside the system and until the lever retracts by itself from the pushing.

#### NOTICE

#### Using lever to push the carrier

When using the lever to push the carrier, it might be damaged.

**It is important that you do not use the lever to insert the disk carrier. Apply an even pressure only to the carrier directly until the lever moves back by itself.**



3. Close the lever until it snaps back in place which as a result will slide the carrier completely back in.



The disk carrier of the replaced disk should be level with the other one of the array.

After several minutes the replaced SSD will be automatically recognized by the system. Then the rebuild of the data will be initiated on its own. When the system has finished the rebuild, the R&S DVS system will be fully operational again.

#### **NOTICE**

#### **Accessing the system disk while rebuild takes place**

A rebuild takes several hours. During a rebuild the performance of the system will be affected and real-time processes may not be possible.

**Rebuild time depends on the load of the system. It is recommended to avoid accesses or at least to restrict accesses to the disk array during this time, otherwise it may take considerably longer.**

### 5.1.4 Replacing a Hard Disk of the Storage Array

As soon as the broken hard disk of the storage array has been identified (see section “Identifying a Broken Disk” on page 5-3), it can be replaced easily.



Before replacing a hard disk you have to gather the log files of the RAID controller. If you know how to do this you may proceed on your own. If not, please contact the R&S DVS service department first.

#### **Removing the Hard Disk from the Array**

The hard disks are connected to the system with the help of disk carriers. They can be removed easily, even when the system is running (hot-swappable).



For an overview of the disk carrier as well as further information about it see section “Hard Disk Array” on page 2-4.

To remove a hard disk from the array perform the following:



1. If appropriate, stop all accesses to the hard disks of your system, for example, by exiting the software and severing the network connections.
2. Unlatch the disk carrier of the defective hard disk by pulling up the opener of the disk carrier.




Figure 5-4: Pulling out the lever

3. Pull the disk carrier out of the system.

Now the hard disk is removed from the system and it has to be replaced in the next step.

### Replacing the Hard Disk in the Array

To replace the hard disk do the following:


#### **NOTICE**

#### **Incorrect handling of the hard disks**

Significant environmental changes, for example, altitude, voltage, temperature, shock, vibration, etc., can damage a hard disk.


**Handle hard disks with great care.**

1. Unlatch the disk carrier of the new hard disk by pulling up the opener of the disk carrier.



It is best to use the same brand and type of hard disk again. Otherwise a loss of performance might occur.

2. Carefully place the carrier from above and close the handle to mount the HDD.

**NOTICE****Danger of damage**

**Carefully place the hard disk carrier into place. Do not let it fall!**



The disk carrier of the replaced disk should be level with the others of the array.



After several minutes the replaced hard disk will be automatically recognized by the system. Then the rebuild of the data will be initiated on its own. When the system has finished the rebuild, the R&S DVS system will be fully operational again.

**NOTICE**

**Accessing the hard disk while rebuild takes place**

A rebuild takes several hours. During a rebuild the performance of the system will be affected and real-time processes may not be possible.

**Rebuild time depends on the load of the system as well as on the capacity of the disks. It is recommended to avoid accesses or at least to restrict accesses to the disk array during this time, otherwise it may take considerably longer.**

## 5.2 Controller Maintenance

During the service life of the R&S DVS system you may have to exchange a RAID controller (see section “Introduction to RAID” on page 5-2). It may be indicated, for example, if a disk set (RAID pack) cannot be accessed anymore. This section describes how to exchange a RAID controller.

### NOTICE

#### Incorrect maintenance

Incorrect exchange of the RAID controller can cause damages to the system.

**Before exchanging a RAID controller contact the R&S DVS service department.**

### DANGER

#### High voltages

The system you are working on operates with voltages that can be hazardous to your health.

**Never work on the system or access its interior with the power cable(s) being plugged in. Make sure the power supply is disconnected from the components you intend to work on.**

**Maintenance inside the system should only be performed by personnel qualified for handling and testing electrical equipment.**

### NOTICE

#### Touching hardware components

Computer hardware contains components that are sensitive to electrostatic discharge. If you touch them without precautionary measures, they can be destroyed.

**Use a wrist strap connected to ground when accessing electronic parts and take care of grounding the system. Avoid touching the internal components of the computer system.**

1. Identify the controller or disk set that causes the problem, for example, by consulting either the RAID software manager or the BIOS of the RAID (press [Ctrl + H on the SpycerBox Ultra TL] at the indicated moment during start-up of the system).
2. Then, open the casing of the system as described in section “Opening the Casing” on page 3-2.
3. On the defective controller memorize the order of the cables that are connected to it. To make this easy the cables are numbered.
4. Disconnect the cables connected to the controller.



5. Remove the defective controller from the system and in its place install a new one.

**NOTICE**
**Other spare parts**

Others than the original manufacturer spare parts might damage your system.

**Only use original manufacturer spare parts.**

**NOTICE**
**Wrong controller firmware**

The wrong controller firmware might lead to incompatibilities and malfunctions of the system.

**The new controller must have the same firmware installed as the other controllers.**

6. Connect the cables to the controller again in the same manner as they were on the old controller.
7. Next close the casing of the system as described in section “Disk Maintenance” on page 5-2.

With the last step finished you have successfully replaced the defective RAID controller. Now, you have to integrate the new controller in the existing configuration:

8. Turn on the system as described in section “Starting the System” on page 4-3.

After the initial booting you will see an output that is similar to the following lines:

Following foreign Arrays are found:

```
<Array>
```

```
Press <Enter> to accept the current configuration
```

```
Press <Ctrl-A> to enter Adaptec RAID Configuration Utility
```

```
Press <Ctrl-H> to Pause Configuration Messages
```

```
(Default is not to accept if no valid key pressed in 30 seconds)
```

9. Press [Enter] on the keyboard to accept the configuration detected by the system.



Depending on the system you have purchased, you may see different lines on the screen and you may have to press e.g. [F] on the SpycerBox Ultra TL to accept the configuration.

After this the newly installed RAID controller automatically initiates a verify of the connected disks which may take some time. When fin-



ished, the system will continue its booting procedure until the operating system is fully loaded. You may then continue your work with the system.



In some cases the boot device cannot be found after accepting a configuration. Then you have to specify the boot device in the BIOS of the RAID. To access the RAID BIOS press [Ctrl + H] at the indicated moment during the start-up of the system. The setting can be found after selecting the respective controller and switching to 'Virtual Drives'.

If the newly installed RAID controller cannot be detected by the system or you see a system message indicating a degraded RAID array, please contact the R&S DVS service department.



## 5.3 Power Supply Maintenance

The redundant power supply provides the system with power. It is a reliable and enduring part of the system because it consists of several independent power supply units: Even if one fails the others will still offer enough power to keep the system working.

### NOTICE

#### Second power supply failure

The system can be operated with one power supply unit out of order. However, if another one fails, a continued operation of the system cannot be guaranteed.

**It is recommended to change a failed power supply unit immediately.**

When a power supply unit failure occurs, you will be notified by a lit alarm LED and the sounding of an alarm buzzer of the system. The alarm can be switched mute with the mute button at the front of the system (see section “Overview of the Front” on page 2-1).



An alarm can be caused by a number of reasons. Please refer to section “Troubleshooting” on page A-2 first for further details about what to do in case of an alarm.

Each power supply unit in the R&S DVS system is hot-swappable, so you can safely replace it with the system running. Follow these steps to replace a power supply unit:



For an overview of a power supply unit see section “Power Supply” on page 2-8.

1. Take a look at the power supply at the rear of the system and examine the LEDs of the units. The LED of the malfunctioning power supply unit should be extinguished.
2. Next unplug the power cord from this power supply unit.
3. Unscrew the security screw of the latch.
4. Take the handle of the respective unit and press the unit's latch to the left to unlock it.

**⚠ DANGER****High voltages**

The system you are working on operates with voltages that can be hazardous to your health.

**Do not reach inside the system when removing a power supply unit or when the unit is out of the system.**

5. Then pull the unit at its handle out of the power supply.
6. Change the power supply unit against a new and operable one.
7. Slide the new unit into the power supply until it clicks into place.

**NOTICE****Other spare parts**

Others than the original manufacturer spare parts might damage your system.

**Only use original manufacturer spare parts.**



When completely inserted please observe that the latch is truly in place and locking the unit.

8. Tighten the security screw of the latch again.
  9. Connect the power source (power cord) to the newly installed power supply unit.
  10. After that check the LED indicating the status of the power supply unit: If it is lit up in green, the unit is working properly.
- With this the power supply unit has been replaced successfully.



## 5.4 Backup or Recovery of the System Disk

The R&S DVS system provides internally a USB flash drive that can be used to back up or restore the operating system on the system disk. With it you can, for example, set the system disk back to its manufacturing state. Once selected as a boot device, it will launch a Live Linux which in turn will either back up or restore the system disk. The following sections describe how to create a backup image or perform a recovery of the system disk.

### 5.4.1 Creating a Backup Image of the System Disk

The following describes the steps to make a backup image of the system disk and save it to the internal USB flash drive:

#### NOTICE

#### Selecting wrong source device

For example, selecting the wrong source device could lead to a full storage space and a termination of the process.

**Do not execute any commands if you are not sure about the correct source and target device.**



To complete the loading of the DVS Rescue environment some user entries are required. For this follow the instructions given on the screen.

The loading of the environment and the process itself will both try to initialize hardware that may not be present on your system. Any error messages displayed during loading/initialization, e.g. *Failed* or *Warning*, can be disregarded. The backup/recovery process should work nonetheless.

The storage space on the USB is limited. The number of backup images that can be stored on the drive, besides the R&S DVS recovery image ex factory available, depends on the size of the image files. If the process fails, the storage drive may be full. However, an already created image can be overwritten when assigning the same name to it.

1. If appropriate, disconnect all Fibre Channel cables and all externally connected storage devices from the system.
2. Turn on or restart the R&S DVS system and at the indicated moment during start-up press [F11] on your keyboard to enter the boot menu.
3. Once the boot menu is displayed on the screen, select the internally installed USB flash drive as the boot device and then press [Enter] on your keyboard.

With this the target device has been selected. The system will now boot from the internal USB and you will see a window on the screen where you can select the DVS Rescue environment for loading:

4. Select `DVS Rescue` and press [Enter] on your keyboard. Once the loading has finished, you will see the DVS Rescue script with its options on the screen. Your display should look similar to the following:

```

--- DVS Rescue ---

1 - Backup on internal USB device
2 - Restore from internal USB device
3 - Reboot the system
4 - Poweroff the system

0 - Exit
  
```

Enter selection:

5. To make a backup image of your system disk and save it to the internal USB, press [1] and then [Enter] on your keyboard. Afterwards a list of possible source devices will be detailed on the screen. In a SpycerBox the system drive normally will be 'sdc', but on special systems it may also be 'sda', 'sdb', etc.



Ex factory the R&S DVS system will be delivered with 'sdc' as the default system disk. If other configurations have been made later or on customer request, this may be different.

#### **NOTICE**

#### **Selecting wrong source device**

Selecting the wrong source device may lead to an unwanted configuration and malfunctions when the system is operating.

**Continue with the following steps only, when you are able to identify the correct source device.**

6. Enter the name of the system disk: Type in `sdc` (or in other cases `sda`, `sdb`, etc.) and press [Enter] on your keyboard. The system will now ask you to enter the image name for your backup image to be saved. By entering the name of an already existing backup image you can overwrite it.
7. Type in the name of the image you want to save to the USB and press [Enter] on your keyboard. The system will ask you to confirm your selection and whether you want to continue:
8. To start the backup process type in `y` for 'yes' and press [Enter] on your keyboard.



To abort the process at this point enter `n` for 'no' and press [Enter] on your keyboard. You will be redirected to the DVS Rescue script. After starting the process a termination is not possible anymore.

The program will now start the backup process. Its progress will be indicated on the screen.



The backup process may take some time. If during the process the screen turns black, press [Space] to get it back again.

When the system has finished the backup process, you will be notified about this. Then after pressing [Enter] on your keyboard, you will be redirected to the DVS Rescue script once more where you can choose, for example, 'reboot' or 'poweroff' to restart or turn off the system.

## 5.4.2 Restoring the System Disk

The following describes the steps to make a recovery of the system disk:

### NOTICE

#### Selecting wrong target device

For example, selecting the wrong target device can lead to a total loss of data.

**Do not execute any commands if you are not sure about the correct source and target device.**



To complete the loading of the DVS Rescue environment some user entries are required. For this follow the instructions given on the screen.

The loading of the environment and the process itself will both try to initialize hardware that may not be present on your system. Any error messages displayed during loading/initialization, e.g. `Failed` or `Warning`, can be disregarded. The backup/recovery process should work nonetheless.

1. If appropriate, disconnect all Fibre Channel cables and all externally connected storage devices from the system.
2. Turn on or restart the R&S DVS system and at the indicated moment during start-up press [F11] on your keyboard to enter the boot menu.



3. Once the boot menu is displayed on the screen, select the internally installed USB flash drive as the boot device and then press [Enter] on your keyboard.

The system will now boot from the internal USB and you will see a window on the screen where you can select the DVS Rescue environment for loading:

4. Select `DVS Rescue` and press [Enter] on your keyboard. Once the loading has finished, you will see the DVS Rescue script with its options on the screen. Your display should look similar to the following:

```
--- DVS Rescue ---  
  
1 - Backup on internal USB device  
2 - Restore from internal USB device  
3 - Reboot the system  
4 - Poweroff the system  
  
0 - Exit
```

Enter selection:

5. To restore your system disk from the internal USB, press [2] and then [Enter] on your keyboard. Afterwards a list of possible target devices will be detailed on the screen. In a SpycerBox Ultra TL the system drive normally will be 'sdc', but on special systems it may also be 'sda', 'sdb', etc.

 Ex factory the R&S DVS system will be delivered with 'sdc' as the default system disk. If other configurations have been made later or on customer request, this may be different.

**NOTICE** **Continuing with the recovery process**  
A recovery will overwrite all your data.  
**Continue with the following steps only, when you are able to identify the correct target device.**

6. Enter the name of the system disk: Type in `sdc` (or in other cases `sda`, `sdb`, etc.) and press [Enter] on your keyboard. Another list will be displayed on the screen detailing the possible source images. If there is only the R&S DVS recovery image on the USB flash drive, this one will be listed. If there are several images, all will be displayed.
7. Select the image you want to use for the recovery. Normally, it provides the serial number of the R&S DVS system in its name. To confirm your choice press [Enter] on your keyboard.



The system will ask you to confirm your selection and whether you want to continue:

8. To start the recovery process type `y` for 'yes' and press [Enter] on your keyboard.



To abort the process at this point enter `n` for 'no' and press [Enter] on your keyboard. You will be redirected to the DVS Rescue script. After starting the process a termination is not possible anymore.

The program will now start the recovery process. Its progress will be indicated on the screen.



The recovery process may take some time. If during the process the screen turns black, press [Space] to get it back again.

When the system has finished the recovery process, you will be notified. Then after pressing [Enter] on your keyboard, you will be redirected to the DVS Rescue script once more where you can choose, for example, 'reboot' or 'poweroff' to restart or turn off the system. The next time the R&S DVS system is started, it will load the restored operating system.



# Appendix

This chapter first gives some hints how to resolve irregularities during operation. After that technical data and general information about the R&S DVS system are provided.



## A.1 Troubleshooting

The table below lists some errors that may occur during the operation of the R&S DVS system and details how to resolve them. If you experience trouble that cannot be resolved with the solutions described here or in chapter “Maintenance” on page 5-1, please contact your local vendor or R&S DVS directly.

Error	Cause	Solution
Accesses to the main storage are slow	The data storage is too full.	It is recommended to use only 85 to 90% of the overall disk capacity. If the storage is too full, delete some of your data.
	One or more hard disks of the hard disk array are worn.	Try to identify the worn disk and replace it as described in section “Disk Maintenance” on page 5-2.
	Configurations of the system or its network ports have been altered.	Contact your local system and network administrator and try to reconfigure the network connections of the system. If this is not successful contact the R&S DVS service department.
	A RAID controller is defective.	If you can rule out the above mentioned causes, a RAID controller may be defective. Before attempting to exchange a RAID controller (see section “Controller Maintenance” on page 5-11) contact the R&S DVS service department.
The system does not boot. Error message: “No operating system found” <i>OR</i> The system cannot find the device to boot from. <i>OR</i>	An external bootable storage device is connected to the system.	Shut down the system as described in section “Shutting Down the System” on page 4-5, disconnect the external bootable storage device and put the system back into operation as described in section “Starting the System” on page 4-3.
		If the system still does not boot correctly, change the boot order in the BIOS setting or contact the R&S DVS service department.
The system boots from an external device.	The boot order in the BIOS settings is wrong.	Correct the boot order in the BIOS setting or contact the R&S DVS service department.
	The system disk(s) is/are broken.	Try to identify the worn disk and replace it as described in section “Disk Maintenance” on page 5-2.

Error	Cause	Solution
<p>An alarm is sounded and the alarm LED is lit. The alarm can be switched mute with the mute button.</p>	<p>One of the power supply units has been disconnected from power during operation.</p>	<p>Check the LEDs of the power supply units. If one is extinguished, this unit may be disconnected from power. Examine the power cord of the unit. See to it that it is in good technical order, correctly plugged in at both ends and that the mains current is operating properly.</p>
	<p>One of the power supply units has failed.</p>	<p>Check the LEDs of the power supply units. If one is extinguished and you can rule out the above mentioned cause, a power supply unit has failed. Replace the broken unit as described in <b>section "Power Supply Maintenance" on page 5-14.</b></p>
	<p>A fan has failed.</p>	<p>If in doubt, whether a fan is defective, please contact R&amp;S DVS support.</p>
	<p>The system is overheated.</p>	<p>If you can rule out the above mentioned causes, the alarm must be due to overheating. See to it that the ambient temperature at the front of the system does not exceed the operating temperature specified in section "Technical Data" on page A-4. If the temperature is within the range, check the ventilation holes of the system and free them from all obstructions (e.g. dust). In case the problem persists, contact the R&amp;S DVS service department.</p>
<p>An alarm is sounded and the alarm LED is off. The alarm cannot be switched mute with the mute button.</p> <p><i>OR</i></p> <p>At start-up the system is not able to initialize a disk set.</p>	<p>A disk or a disk carrier got loose/jammed (e.g. after transport) or is not mounted correctly.</p>	<p>Shut down the system as described in section "Shutting Down the System" on page 4-5. Then perform the following: Pull all disk carriers partially out of the chassis and afterwards install them again. See to it that they are pulled out and reassembled correctly as described in section "Replacing a System Disk" on page 5-5. After that start the system again.</p>
	<p>A hard disk of the hard disk array is defective.</p>	<p>Replace the defective disk as explained in section "Disk Maintenance" on page 5-2.</p>
	<p>A RAID controller is defective.</p>	<p>If you can rule out the above mentioned causes, a RAID controller may be defective. Before attempting to exchange a RAID controller (see section "Controller Maintenance" on page 5-11) contact the R&amp;S DVS service department.</p>



## A.2 Technical Data

This section provides technical data of the SpycerBox Ultra TL.



When installing the R&S DVS system in a rack, take care that warmed up air is conducted to the rear of the rack and properly vented away. The technical data may vary depending on the system and its equipment.

### A.2.1 General Technical Data

The general technical data of the SpycerBox Ultra TL are as follows:

Chassis weight	Approx. 36.7 kg
Chassis weight with drives	Approx. 67.9 kg
Environment (also during transport)	No exposure to heat No exposure to strong electric or magnetic fields No vibrations/shocks allowed
Operating temperature	Maximum: 10 - 30 °C (50 - 86 °F) Optimum: 15 - 25 °C (59 - 77 °F)
Storage temperature	0 - 50 °C (32 - 122 °F)
Humidity	10% to 80% RH @ 30°C, non-condensing
Non-operating humidity	Up to 85% RH @ 30°C, non-condensing
Air	Dust-free
Power consumption	1184 W max. input power 911.4 W typ. input power 641 W idle power
Input power requirements	100 - 240 V @ 47 - 63 Hz

## A.2.2 Dimensions

The following figure shows the dimensions of the R&S DVS system. The drawing already includes some space for connectors and plugs that can protrude from the rear ('plug safety' ( $l$  minus  $j$ ), usually plus 150 mm). However, this amount of space depends on the type of connectors used.




Figure A-1: Measured dimensions

a	438 mm	b	795 mm
c	480 mm	d	11 mm
e	10 mm	f	44 mm
g	2 mm	h	12 mm
i	5 mm	j	176 mm



## A.3 Packing Instructions

The following describes the best way to pack a R&S DVS system.

### NOTICE

#### Incorrect packaging

The warranty will be void if you do not transport the R&S DVS device in the original packing.

**You have to keep the original packing and use it in case of transportation.**

**In any other case, if you do not have the original packing anymore, use a similar structured packing for transportation. R&S DVS cannot be held liable for damages due to transportation.**



Fragile. Avoid shocks or vibrations. For longer distances use a lifting truck.



Keep dry.

### NOTICE


#### Incorrect packaging

The hard disks may be damaged during transport if still installed in the system.


**Remove the hard disk sets (left and right) before transportation. Always transport the hard disks in a separate packing.**

Perform the following steps:


1. Wrap the system in foil:




- Pack the system in the box and place it on the pallet.



- Pack the accessories in a box:




- Place the hard disks of the left and right disk sets in the original tablets provided. Pack the tablets in the appropriated boxes.





5. Place all the boxes on the pallet as shown:



## A.4 Conformity Declarations

The SpycerBox Ultra TL has been tested according to the applying national and international directives and regulations. The following states further information about the compliances and conformities.

### A.4.1 RoHS Compliance

The EU directive 2002/95/EC 'Restriction of Hazardous Substances (RoHS)' prohibits the use of certain substances in electrical and electronic equipment. The SpycerBox Ultra TL device is manufactured in compliance with this directive.

### A.4.2 EC Declaration of Conformity (CE Marking)

Rohde & Schwarz DVS GmbH herewith declares that the following product(s) according to the provisions of the mentioned EC Directives – including their relevant revisions at the time of this declaration – is (are) in conformity with the detailed standards or other normative documents:

<b>SpycerBox Ultra TL</b>	EC Directives: <ul style="list-style-type: none"> <li>▪ EMC Directive 2004/108/EC</li> <li>▪ Low-Voltage Directive 2006/95/EC</li> </ul>
	Applied Harmonized Standards: <ul style="list-style-type: none"> <li>▪ EN 55022</li> <li>▪ EN 55024</li> <li>▪ IEC 61000-3-2</li> <li>▪ IEC 61000-3-3</li> <li>▪ IEC 61000-4-2</li> <li>▪ IEC 61000-4-3</li> <li>▪ IEC 61000-4-4</li> <li>▪ IEC 61000-4-5</li> <li>▪ IEC 61000-4-6</li> <li>▪ IEC 61000-4-11</li> <li>▪ IEC 61000-4-29</li> </ul>



### A.4.3 FCC Compliance Statement

Rohde & Schwarz DVS GmbH herewith declares that the following equipment has been tested according to the applying valid FCC regulations:

- SpycerBox Ultra TL

#### FCC Notice

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

**Note:** Connecting this device to peripheral devices that do not comply with Class A requirements or using an unshielded peripheral data cable could also result in harmful interference to radio or television reception. The user is cautioned that any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. To ensure that the use of this product does not contribute to interference, it is necessary to use shielded I/O cables.

# Index

## A

alarm ..... 2-3, A-3  
 fan failure ..... A-3  
 hard disk failure ..... 5-3, A-3  
 LED ..... 5-14, A-3  
 overheating ..... A-3  
 power supply unit failure ... 5-14, A-3  
 RAID controller ..... 5-3, A-2, A-3  
 ATX connector panel ..... 2-5, 2-7

## B

backup image of the system disk ..... 5-16  
 battery backup ..... 2-6

## C

cache protection unit ..... 2-12  
 casing  
   close ..... 3-5  
   location of battery backup ..... 2-12  
   open ..... 3-2  
 closing of casing ..... 3-5  
 COM port ..... 2-7  
 configuration ..... 4-4  
 conformity declaration ..... 1-7, A-9  
 connectors  
   ATX connector panel ..... 2-5, 2-7  
   slot panels ..... 2-6, 2-9  
 conventions  
   screenshots ..... 1-3  
 conventions (typographical) ..... 1-1

## D

data loss ..... 2-4, 2-6, 2-12  
 data protection ..... 5-2  
 declaration of conformity ..... 1-7, A-9  
 dimensions ..... A-5  
 disk carrier ..... 2-6, 5-5, 5-7  
   overview ..... 2-6  
 disk set (RAID pack) ..... 5-2

disk(s)  
   system/metadata ..... 2-6  
 DVS Rescue ..... 5-17, 5-19

## E

environmental conditions ..... 1-5, A-4  
 Ethernet ..... 2-8  
 exchanging  
   hard disk ..... 5-7  
   power supply unit ..... 5-14  
   RAID controller ..... 5-11

## F

faceplate  
   removal ..... 4-2  
 fan failure ..... A-3  
 fast shut down ..... 4-5  
 Fibre Channel  
   configuration ..... 4-4  
 front overview ..... 2-1

## G

guarantee ..... 1-6

## H

handle ..... 2-9  
 hard disk array ..... 2-4  
 hard disk(s) ..... 2-4  
   assembly ..... 5-6  
   disk set (RAID pack) ..... 5-2  
   failure ..... 5-2  
   rebuilding failed disk ..... 5-7, 5-10  
   removal ..... 5-7  
   replace ..... 5-7, 5-8  
   system/metadata ..... 5-2  
 hard disks  
   installation ..... 3-3  
 hardware variants ..... 2-1

**I**

important notes .....	1-6, 1-7
installation .....	3-1, 3-5
hard disks .....	3-3
network .....	3-6
instructions	
installation .....	3-1, 3-5
maintenance .....	5-1
operation .....	4-1
packing .....	A-6
safety .....	1-4
IP address .....	4-4
IPMI .....	2-8

**K**

keyboard .....	3-5
KVM .....	2-8

**L**

LAN .....	2-8
latch .....	2-9
LEDs	
alarm .....	5-14, A-3
power supply .....	2-9, 5-14
log files .....	4-4

**M**

main storage .....	2-4
metadata HDD .....	2-6, 5-2
monitor .....	3-5
mouse .....	3-5
mute button .....	2-3, 5-14, A-3

**N**

network .....	2-8
connection .....	2-8
connection possibilities .....	2-9
installation .....	3-6
notes (important) .....	1-6, 1-7

**O**

opening of casing .....	3-2
operating system .....	2-6
operation items .....	2-2
overheating .....	A-3
overview	
disk carrier .....	2-6

front .....	2-1
power supply unit .....	2-8
rear .....	2-5

**P**

packing instructions .....	A-6
parity information (RAID) .....	5-2, 5-3
power .....	2-3
switch .....	2-3, 4-1
power cable socket .....	2-9
power supply .....	2-6
handle .....	2-9
latch .....	2-9
LED .....	2-9
overview of one unit .....	2-8
power cable socket .....	2-9
status of unit .....	2-9
unit failure .....	5-14, A-3
power switch .....	2-3, 4-1
proxy .....	2-4

**R**

R&S DVS configuration management	
software .....	4-4
RAID .....	2-4, 2-6, 5-2
controller .....	2-12, 5-2, 5-3
controller exchange .....	5-11
disk set (RAID pack) .....	5-2
parity information .....	5-2, 5-3
rebuilding failed disk .....	5-7, 5-10
rear overview .....	2-5
reboot .....	4-4
rebuilding failed disk .....	5-7, 5-10
removal of the faceplate .....	4-2
replacing a hard disk .....	5-7
reset button .....	2-3
restoring the system disk .....	5-18
RS-232 .....	2-7

**S**

safety instructions .....	1-4
SAN Remo .....	4-4
shutting down .....	4-4, 4-5
fast shut down .....	4-5
slot panel connectors .....	2-6, 2-9
SpycerBox	
configuration .....	4-4
installation .....	3-1, 3-5
log files .....	4-4
main storage .....	2-4



metadata .....	2-6, 5-2	technical data .....	A-4
operating system .....	2-6	dimensions .....	A-5
reboot .....	4-4	general .....	A-4
shut down .....	4-4, 4-5	transportation .....	1-5, A-6
start .....	4-3	troubleshooting .....	4-4, A-2
storage capacity .....	2-1	typographical conventions .....	1-1
technical data .....	A-4		
variants .....	2-1	<b>U</b>	
starting .....	4-3	USB connectors .....	2-8
status			
of power supply unit .....	2-9	<b>V</b>	
storage capacity .....	2-1	variants .....	2-1
stripe set .....	5-2	VGA .....	2-8
system disk array .....	2-5		
system HDD .....	2-6, 5-2	<b>W</b>	
system power loss .....	2-12	warranty .....	1-6
system reset .....	2-3	workflow .....	3-6
system/metadata HDD .....	5-2		
system/metadata SSD .....	2-6		
<b>T</b>			
target group .....	1-1		

